

## ■ Scene Play Preset List

	Category	Title	Scene Setting
①	Composer	Chopin	Setting oriented toward performances of Chopin and other representative Romantic movement music
②		Beethoven	Setting oriented toward performances of Beethoven and other representative Classical movement music
③		Debussy	Setting oriented toward performances of Debussy and other representative Impressionist movement music
④		Liszt	Setting oriented toward performances of Liszt and other representative Transcendentalist movement music
⑤		Satie	Setting oriented toward performances of Satie and other representative modern era music
⑥	Musical genre	EZ Listening	Setting oriented toward performances of easy-listening music
⑦		Jazz	Setting oriented toward jazz piano performances
⑧	Tones	Baroque	Setting oriented toward performances of J.S. Bach and other representative Baroque era music
⑨		Toccat & Fuge	Setting for music such as pipe organ performances in a cathedrals
⑩		Ragtime	Setting oriented toward performances of ragtime music
⑪	Place	Lesson	Setting oriented toward performances of practice pieces
⑫		Concert	Setting oriented toward concert or recital practice
⑬		Listener	Setting oriented toward practice while confirming audibility for audience
⑭	Store demo	Extreme Demo	Setting for making acoustic simulator effects conspicuous and easily accessible
⑮	Reset	Default	Setting of initial BERLIN GRAND tone status